



In order to properly size a Roma Roman blind it is necessary to assume:

- **width** -to the width of the window recess add at least 5 cm on each side, depending on the length of the curtain rod
- **length** - enter the total length of the blind (before tying up) and assume that the bamboo stick is in the middle length, and the frill after after tying up is about 30 cm.

Example: if we want to have 100 cm long tied blind (incl. valance), you must order a blind length $(100 \text{ cm} - 30 \text{ cm}) \times 2 = 140 \text{ cm}$.

It is not possible to pull up the blind.

