

THE TAB TOP ROMAN BLIND - MEASURING



In order to properly size the tab top Roman blind, it is necessary to assume:

- width - to the width of the window recess add at least 5 cm on each side, depending on the length of the curtain rod

- length - measure the height from the curtain rod to the windowsill - remember that completely rolled up blind takes up about 25-35 cm.

