

ROMAN BLIND FOR ROOF WINDOW MEASUREMENT FOR WINDOW RECESS



Add exactly 7 centimetres on each side to the width of the window recess to obtain the correct width of the blind.

The height of the roller shutter is the height of the window recess plus min. 10 cm from the upper edge of the bay and min. 8 cm from the bottom edge of the bay.

If you do not have the required space (10 cm from the top or 8 cm from the bottom edge of the window recess), please contact the customer service office.

